



Fitting Instructions 002

Land Rover Freelander 1 1997 - 2004

Please be advised this is not compatible with the Facelift 2004-2006 model

IMPORTANT PREPARATION NOTES

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE VELCRO ADHESIVE TAKES 24HRS TO REACH FULL ADHESION.

1. Remove rear headrests
2. Place the metal D Rings located on the rear edge of the cargo liner over the headrest locator holes
3. Replace headrest arms through the metal D Rings
4. Fit the cargo liner into place
5. To secure into place, attach the elastic tapes located on the sides of the liner to the T-bars fitted in the Freelander

To obtain the perfect fit, we have supplied 2 x 20" lengths of Velcro - these can be attached to the sides of your Freelander and will attach to the top of the liner (which is also fitted with Velcro). The liner may be used with or without the Velcro.

Please note: If you are using this liner in conjunction with the Land Rover dog guard; imagine you are at the rear of the vehicle looking in, with the D rings being numbered 1-6, numbers 2 and 5 cannot be used.