



NORTH AMERICAN CUSTOM COVERS

Fitting Instructions - BMW X3 2004-2011 (009)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

IMPORTANT PREPARATION NOTES

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. **ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE VELCRO ADHESIVE TAKES 24HRS TO REACH FULL ADHESION.**

ATTACH THE BASE FIRST ...

1. Unlock the rear seat backs and fold forward a little, and lay the liner in approximate position in the trunk of your vehicle. The panel with the North American Custom Covers label attached sits against the back of the rear seat, facing outward.
2. At the seat end of the base, locate the two foam pads and push them down into the void between the floor and the seat backs. Lock the rear seats back into position trapping in the foam pads.
3. At the tailgate end of the base attach four 2 inch long Velcro strips to the 4 Velcro strips sewn onto the base of the liner, then attach directly to the carpet using the liner as your guide.

NOW FOR THE BACK OF THE SEATS ...

4. At the top of the seat area of the liner there are 4 lengths of material. Attach each of the 4 around each headrest pole and secure back on to itself.

NOW THE SIDES ...

5. Open the access panel located on the left and right hand side of the vehicle and place the large elastic loop over the top, then close shut to secure.
6. On the left hand side of the liner attach three 2 inch and one 6 inch long strips of Velcro to the corresponding Velcro strips sewn onto the sides of the liner. On the right hand side attach two 2 inch and one 10 inch strips. Using the liner as a guide attach each side directly to the side carpet.

BUMPER FLAP ...

7. To position the bumper flap in the upright position, attach the 2 pieces of 4 inch Velcro to the large Velcro tabs sewn onto either side of the bumper flap. Remove the backer on the adhesive-backed Velcro and, using the liner as a guide, attach these in the gutters of the tailgate.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD