



Fitting Instructions - BMW X5 2000-2006 (010)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

1. Remove Parcel Shelf
2. Remove Rear Headrests
3. Place the metal D Rings located on the rear edge of the cargo liner over the headrest locator holes
4. Replace headrest arms through the metal D Rings
5. Fit the cargo liner into place
6. To hold the sides of the cargo liner in place, open the access panels on each side of the vehicle and place the 4 tabs sewn onto the liner into the access panels and close to secure.
7. Replace parcel shelf
8. The elastic on the top corners of the bumper flap can be fitted to the rubber trunk stops to protect the tailgate.

PLEASE NOTE: Once the liner has been installed - Before lowering the rear seats you must remove the D Rings from the rear headrests - failure to do this could damage the liner. North American Custom Covers will be unable to replace or refund any damaged liners where the above has occurred.

