



NORTH AMERICAN CUSTOM COVERS

Fitting Instructions - Land Rover LR2 (Freelander) 2006 to 2015 (023)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

IMPORTANT PREPARATION NOTES

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. **ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE**

1. Before you start you'll need to cut the supplied Velcro as follows for the main liner: 14 x 2" long pieces, 2 x 13" long pieces, 2 X 4" long pieces. Now lay the liner in approximate position in the trunk of your vehicle. The panel with the North American Custom Covers label attached sits against the back of the rear seat, facing outward.

ATTACH THE BASE FIRST ...

2. Attach the 2 ties located on the base of liner to the adjacent luggage tie down hooks.
3. At the tailgate end where the liner meets the rear of the vehicle (NOT the bumper flap) attach 6 of the 2 inch long adhesive-backed Velcro strips supplied to the 6 Velcro strips sewn onto the base of the liner, then attach this directly to the carpet using the liner as your guide.

NOW FOR THE BACK OF THE SEATS ...

4. At the top of the seat area of the liner there are 6 lengths of material. Attach each of these around each headrest pole and secure back on to itself.
5. Attach the elastic loops around and under the plastic mouldings that house the rear seat unlock buttons.

Velcro Fixing Kit - 14 x 2 inch plus 2 x 13 inch plus 2 x 4 inch
(62 inch velcro strip supplied, please cut to length as required)



NOW THE SIDES ...

6. Attach 4 of the 2 inch long, and 1 of the 13” long, adhesive-backed Velcro pieces to the corresponding Velcro points on each liner side. Carefully position the side panels neatly into place, working from the bottom upwards, peeling off each backer piece as you go, and attaching directly to the side trim.
7. There are 2 ties attached to the topsides, these should be attached to the exposed rear seat locking catches.

BUMPER FLAP ...

8. To position the bumper flap in the upright position, attach the 2 pieces of 4 inch Velcro to the large Velcro tabs sewn onto either side of the bumper flap. Remove the backer on the adhesive-backed Velcro and, using the liner as a guide, attach these in the gutters of the tailgate.

THAT'S IT, YOU'RE FINISHED.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD