



# NORTH AMERICAN CUSTOM COVERS

## Fitting Instructions - Land Rover Range Rover Sport 2005 to 2013 (024)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

### IMPORTANT PREPARATION NOTES

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE VELCRO ADHESIVE TAKES 24HRS TO REACH FULL ADHESION.

1. Before you start you'll need to cut the supplied Velcro as follows for the main liner: 27 x 2" pieces, 2 x 4" pieces. Now lay the liner in approximate position in the trunk of your vehicle. The panel with the North American Custom Covers label attached sits against the back of the rear seat, facing outward.

#### ***ATTACH THE BASE FIRST ...***

2. There is an under flap sewn into the tailgate edge of the liner. This sits over the leading edge of the lift up floor section. Position into place then, using six pieces of 2 inch adhesive-backed Velcro, attach to the underside of the floor.
3. Attach the 3 ties located on the base of liner to the adjacent luggage tie down hooks.

#### ***NOW FOR THE BACK OF THE SEATS ...***

4. At the top of the seat area of the liner there are 6 lengths of material. Attach each of the 6 around each headrest pole and secure back on to itself.

#### ***NOW THE SIDES ...***

5. Attach 21 of the 2 inch adhesive-backed Velcro pieces to the corresponding Velcro points on the liner sides. Carefully position the side panels neatly into place, working from the bottom upwards, and peeling off each backer piece as you go.

#### ***BUMPER FLAP ...***

6. To position the bumper flap in the upright position, attach the 2 pieces of 4 inch Velcro to the large Velcro tabs sewn onto either side of the bumper flap. Remove the backer on the adhesive-backed Velcro and, using the liner as a guide, attach these in the gutters of the tailgate.

**PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD**

Velcro Fixing Kit - 27 x 2 inch, 2 x 4 inch  
(1 x 62 inch adhesive-backed Velcro strip supplied, please cut to required lengths)