



NORTH AMERICAN CUSTOM COVERS

Fitting Instructions - Volvo XC90 2002 to 2014 (032)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

IMPORTANT PREPARATION NOTES

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. **ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE VELCRO ADHESIVE TAKES 24HRS TO REACH FULL ADHESION.**

PART 1 - THE MAIN LINER

1. Before you start you'll need to cut the supplied Velcro as follows for the main liner: 16 x 2" pieces, 2 x 14" pieces. Now lay the liner in approximate position in the trunk of your vehicle.

ATTACH THE BASE FIRST ...

2. On the underside of the liner floor, at the base of the seat area, you will find 2 lengths of material sewn in on each side. Attach these to the relevant areas of your cargo floor with a simple knot.
3. On the liner floor area, at the tailgate end you will find a pocket the width of the tailgate flap, position this over the tailgate flap.

NOW FOR THE BACK OF THE SEATS ...

4. At the top of the seat area of the liner there are 4 lengths of material and a central elasticated length. Attach each of the 4 around each headrest pole and secure back on to itself. Loop the elasticated part around the centre headrest and back onto the liner.

NOW THE SIDES ...

5. Attach the pieces of Velcro that you cut earlier directly to the sewn in Velcro points on each side. Using the liner as a guide affix the Velcro to the sides of your vehicle.

PART 2 - OPTIONAL TAILGATE PROTECTOR

6. If you install this piece, before you start you'll need to cut the supplied Velcro as follows: 19 x 2" pieces, 1 x 40" piece. Attach the pieces of Velcro that you've cut directly to the sewn in Velcro points on the tailgate protector, and using the liner as a guide fix to the tailgate.

THAT'S IT, YOU'RE FINISHED.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD.