



Fitting Instructions - Mercedes ML 2005 to 2011 (046)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

This is a 2 part liner.

PART 1 *(the main liner)*

1. Lay the liner in approximate position in the trunk of your vehicle. The panel with the North American Custom Covers label attached sits against the back of the rear seat, facing outward.

ATTACH THE BASE FIRST ...

2. Starting at the tailgate end, neatly align and then press down the Velcro sewn into the floor section of the liner directly to the carpet and repeat as you work towards the rear seats.

NOW FOR THE BACK OF THE SEATS ...

3. At the top of the liner where it meets the rear seat back (under the headrests) there are 6 x 2" Velcro strips sewn in to the liner, using the liner as a guide press to attach to the carpet on the back of the seats.
4. At the top of the seat area of the liner there are 5 lengths of material. Attach each of the 5 around each headrest pole and secure back on to itself.

NOW THE SIDES ...

5. Carefully position the side panels neatly into place, the Velcro sewn onto the sides of the liner will attach directly to the carpet.

PART 2 *(optional tailgate protector)*

6. Align the tailgate protector with the carpeted area on the tailgate. Press the 10 x 2" pieces of Velcro sewn in to the liner to the carpet of the tailgate.

THAT'S IT, YOU'RE FINISHED.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS, and UNHOOK THE VELCRO AT THE TOP OF THE SEATS, BEFORE PLACING THE REAR SEATS FORWARD.