



## Fitting Instructions – Audi A4 Wagon (067)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

1. Remove luggage blind
2. Remove rear headrests
3. Place the metal D Rings located on the rear edge of the cargo liner over the headrest locator holes
4. Replace headrest arms through the metal D Rings
5. Fit the cargo liner into place
6. There are 4 securing tapes on the base of the liner – attach these to the relevant hooks in the floor
7. To secure the sides of the liner; Open the 2 access panels located in the left and right hand side of the luggage area. Attach the Velcro tapes on the sides of the liner to the back of the access panels and close

### IMPORTANT NOTICE – PLEASE READ BEFORE USE

Once the liner has been installed - Before lowering the rear seats you must remove the D Rings from the rear headrests – failure to do this could damage the liner.

North American Custom Covers will be unable to replace or refund any damaged liners where the above has occurred