



NORTH AMERICAN CUSTOM COVERS

Fitting Instructions - Audi Q5 2008-2017 (074)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

IMPORTANT GENERIC PREPARATION NOTES

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. **ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE VELCRO ADHESIVE TAKES 24HRS TO REACH FULL ADHESION.**

Before you start, lay the liner in approximate position in the trunk of your vehicle. The panel with the North American Custom Covers label attached sits against the back of the rear seat, facing outward.

ATTACH THE BASE FIRST ...

1. Starting at the tailgate end where the liner base meets the rear of the vehicle, attach the Velcro sewn onto the underside of the liner directly to the carpet.

NOW FOR THE BACK OF THE SEATS ...

2. At the top of the seat area of the liner there are 6 lengths of material. Attach each of the 6 around each headrest pole and secure back on to itself.

NOW THE SIDES ...

3. Carefully position the side panels neatly into place, the Velcro sewn onto the sides of the liner will attach directly to the carpet.

BUMPER FLAP ...

4. To position the bumper flap in the upright position, attach the 2 pieces of 4 inch Velcro to the large Velcro tabs sewn onto either side of the bumper flap. Remove the backer on the adhesive-backed Velcro and, using the liner as a guide, attach these in the gutters of the tailgate.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD