



Fitting Instructions – Mini /BMW Countryman Raised Floor 2010 Onwards (078)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

IMPORTANT PREPARATION NOTES

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE VELCRO ADHESIVE TAKES 24HRS TO REACH FULL ADHESION.

1. Before you start you'll need to cut the supplied Velcro as follows for the liner: 2 x 13" long pieces, 2 x 4" long pieces. Now lay the liner in approximate position in the trunk of your vehicle. The panel with the Custom Covers label attached sits against the back of the rear seat.

ATTACH THE BASE FIRST ...

2. Attach the four ties on the underside of the base to the tie down hooks – do not over tighten as this will cause the base of the liner to lift up from the cargo floor.
3. At the tailgate end where the liner meets the rear of the vehicle (NOT the bumper flap) attach 2 of the 13 inch Velcro strips supplied to the 2 Velcro strips sewn onto the base of the liner, then attach this directly to the tailgate trim using the liner as your guide.

NOW FOR THE BACK OF THE SEATS ...

4. At the top of the seat area of the liner there are 4 lengths of material. Attach each length around each headrest pole and secure back on to itself.

NOW THE SIDES ...

5. Carefully position the side panels neatly into place, the Velcro sewn onto the sides of the liner will attach directly to the carpet.

BUMPER FLAP ...

6. To position the bumper flap in the upright position, attach the 2 pieces of 4 inch Velcro to the large Velcro tabs sewn onto either side of the bumper flap. Remove the backer on the adhesive-backed Velcro and, using the liner as a guide, attach these in the gutters of the tailgate.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD. THE CARGO LINER WILL NOT ACCOMMODATE THE LOAD RETENTION SYSTEM.

Velcro Fixing Kit - 2 x 13 inch plus 2 x 4 inch
(34 inch strip supplied, please cut to required lengths)