



Fitting Instructions -

Audi A6 Avant Wagon 2011 onwards - Generation 4 - Cargo Liner (BL079)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

This is a 2 part liner.

PART 1 - THE MAIN LINER

1. Before you start you'll need to cut the supplied Velcro as follows for the main liner: 6 x 2" long pieces, 3 x 5" long pieces. Now lay the liner in approximate position in the trunk of your vehicle. The panel with the Custom Covers label attached sits against the back of the rear seat, facing outward.

ATTACH THE BASE FIRST ...

2. Unlock the rear seat backs and fold forward a little.
3. At the seat end of the base, locate the two foam pads and push them down into the void between the floor and the seat backs. Lock the rear seats back into position trapping in the foam pads.
4. Carefully align the rest of the base of the liner in the floor of the vehicle.
5. Attach 3 of the 5 inch long Velcro strips supplied, to the Velcro strips sewn onto the tailgate of the liner (see sketch A), and attach these directly to the tailgate trim using the liner as your guide.

NOW FOR THE BACK OF THE SEATS ...

6. At the top of the seat area of the liner there are 6 lengths of material. Attach each of the 6 around each headrest pole and secure back on to itself.

NOW THE SIDES ...

7. Open the access panel located on the left and right hand side of the vehicle and place the large elastic loop over the top, then close shut to secure.
8. On the left and right hand side of the liner attach 3 of the 2 inch strips of Velcro supplied to the corresponding Velcro strips sewn onto the sides of the liner. Using the liner as a guide attach directly to the side carpet.
9. Attach the hooks to the rear seat locking points - Lock the rear seats back into position. Stretch the bungee eye on to the relevant side hooks (Figure 1 & 2)
10. Tuck the leading edge of the liner behind the tailgate seal.

PART 2 - REMOVABLE BUMPER FLAP

11. Match the "hook" Velcro on the removable bumper flap to the "loop" Velcro on the main liner near the tailgate.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS, & VELCRO ON THE SEAT BACKS, BEFORE PLACING THE REAR SEATS FORWARD.



Figure 1 - Plastic hook attaches to seat locking point



Figure 2 - Bungee eye attaches to side hook



Figure 3 - Tuck leading edge behind rubber seal

IMPORTANT PREPARATION NOTES

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE VELCRO ADHESIVE TAKES 24HRS TO REACH FULL ADHESION.

SKETCH A

■ = INDICATES AREAS WHERE A 2" ADHESIVE-BACKED VELCRO PIECE NEEDS TO BE APPLIED

