



Fitting Instructions - VW Golf Hatchback Mk6 2009 to 2012 (086)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

IMPORTANT PREPARATION NOTES

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE VELCRO ADHESIVE TAKES 24HRS TO REACH FULL ADHESION.

1. Before you start you'll need to cut the supplied Velcro as follows: 24 x 2" long pieces, 2 x 4" long pieces.

THE BASE OF THE SEATS SHOULD BE IN THE REAR POSITION

ATTACH THE BASE FIRST ...

2. Now lay the liner in approximate position in the trunk of your vehicle. The panel with the Custom Covers label attached sits against the back of the rear seat.
3. At the tailgate end where the liner meets the rear of the vehicle (NOT the bumper flap) attach 8 of the 2 inch long Velcro strips you've already cut to the 8 Velcro strips sewn onto the base of the liner, then attach this directly to the tailgate trim using the liner as your guide.
4. Attach the ties on either side to the nearby cargo hooks.

NOW FOR THE BACK OF THE SEATS ...

5. At the top of the seat area of the liner there are 4 lengths of material. Attach each around the headrest poles on the left and right seat, and secure back on to itself.

NOW THE SIDES ...

6. Attach the pieces of Velcro that you cut earlier directly to the sewn in Velcro points on each side (8 x 2" to each side). Using the liner as a guide affix the Velcro to the sides of your vehicle.

BUMPER FLAP ...

7. To position the bumper flap in the upright position, attach the 2 pieces of 4 inch Velcro to the large Velcro tabs sewn onto either side of the bumper flap. Remove the backer on the adhesive-backed Velcro and, using the liner as a guide, attach these in the gutters of the tailgate.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD.