



Fitting Instructions - Audi Q3 RAISED Floor 2011 onwards (168)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

PLEASE NOTE THE BASE OF THE SEATS SHOULD BE IN THE REAR POSITION

ATTACH THE BASE FIRST ...

1. Lay the liner in approximate position in the trunk of your vehicle. The panel with the Custom Covers label attached sits against the back of the rear seat, facing outward.
2. The Velcro sewn onto the underside of the liner will attach directly to the carpet.

NOW FOR THE BACK OF THE SEATS ...

3. At the top of the seat area of the liner there are 6 lengths of material. Attach each of the 6 around each headrest pole and secure back on to itself.

NOW THE SIDES ...

4. Carefully position the side panels neatly into place, working from the bottom upwards. The Velcro sewn in to the liner attaches directly to the carpet.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD