



Fitting Instructions - Land Rover Discovery Sport (173)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

IMPORTANT PREPARATION NOTES

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. **ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE**

PART 1 - THE MAIN LINER

ATTACH THE BASE FIRST ...

1. Place the piece labelled part 1 in the vehicle so that the base fits neatly into position. The panel with the North American Custom Covers label attached sits against the back of the rear seat, facing outward. Have the sides folded on top of the base, and the liner seat backs folded on top of that, so the sewn in Velcro on these areas doesn't stick to the carpeted areas when you're aligning the base.
2. Starting at the tailgate end, neatly align and press down the Velcro sewn in to the floor section of the liner directly to the carpet.

NOW FOR THE BACK OF THE SEATS ...

3. Starting from the base of the seats, work upwards aligning the sewn in Velcro to the seat backs.
4. Pass the tapes at the top of the seat backs around each headrest locator pole and Velcro back onto themselves.

NOW THE SIDES ...

5. Carefully position the side panels neatly into place, the Velcro sewn onto the sides of the liner will attach directly to the carpet.

PART 2 - REMOVABLE BUMPER FLAP

1. Match the "hook" Velcro on the removable bumper flap to the "loop" Velcro on the main liner near the tailgate.

PART 3 - OPTIONAL UPPER TAILGATE PROTECTOR

1. If you install this piece, before you start you'll need to cut the supplied Velcro as follows: 20 x 2" pieces. Attach the pieces of Velcro that you've cut directly to the sewn in Velcro points on the tailgate protector, and using the liner as a guide fix to the upper tailgate.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO ON THE SEAT BACKS AND THE HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD.

Velcro Fixing Kit -1 x 40 inch Velcro strip supplied, please cut to required lengths