



Fitting Instructions - VW Touareg 2011 on (241)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

Our liner requires your rear seats to be in the fully upright position and the base to be positioned as far back as possible.



Before you start, lay the liner in approximate position in the trunk of your vehicle. The panel with the Custom Covers label attached sits against the back of the rear seat, facing outward.

ATTACH THE BASE FIRST ...

1. Starting at the tailgate end where the liner base meets the rear of the vehicle, attach the Velcro sewn onto the underside of the liner directly to the carpet.

NOW FOR THE BACK OF THE SEATS ...

2. At the top of the seat area of the liner there are 6 lengths of material. Attach each of the 6 around each headrest pole and secure back on to itself.

NOW THE SIDES ...

3. Carefully position the side panels neatly into place, the Velcro sewn onto the sides of the liner will attach directly to the carpet.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS & THE VELCRO ON THE SEAT BACKS BEFORE PLACING THE REAR SEATS FORWARD