



Fitting Instructions – Volvo XC90 2015 onwards – 7 Seater model only (255)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

IMPORTANT PREPARATION NOTES

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE VELCRO ADHESIVE TAKES 24HRS TO REACH FULL ADHESION.

1. Before you start you'll need to cut the supplied Velcro as follows for the main liner: 2 x 16" pieces, 2 x 17" pieces and 4 x 2" pieces. Now lay the liner in approximate position in the trunk of your vehicle.

ATTACH THE BASE FIRST ...

2. Unlock the rear seat backs and fold forward a little.
3. At the seat end of the base, locate the two foam pads and push them down into the void between the floor and the seat backs. Lock the rear seats back into position trapping in the foam pads.
4. At the tailgate end where the liner meets the rear of the vehicle (NOT the bumper flap), attach 2 of the 17 inch long Velcro strips supplied to the Velcro strips sewn onto the liner tailgate. Then, using the liner as a guide, peel the backer tape off the Velcro and attach directly to the tailgate.

NOW FOR THE BACK OF THE SEATS ...

5. At the top of the seat area of the liner there are 4 lengths of material. Attach each of the 4 around each headrest pole and secure back on to itself.

NOW THE SIDES ...

6. If your vehicle has carpeted sides, the liner will attach directly to the carpet. Otherwise, attach the pieces of Velcro that you cut earlier directly to the sewn in Velcro points on each side of the liner. Using the liner as a guide affix the Velcro to the sides of your vehicle.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD.

SKETCH A

— = AREA WHERE ADHESIVE-BACKED VELCRO NEEDS TO BE APPLIED

