



Fitting Instructions - Honda CR-V Generation 4 Model Years 2012 to 2016 (BL322)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

This is a 2 part liner.

PART 1 - THE MAIN LINER

1. Before you start you'll need to cut the supplied Velcro as follows for the main liner: 6 x 2" long pieces, 2 x 27" long pieces and 2 x 18" long pieces.

ATTACH THE BASE FIRST ...

2. Lay the liner in approximate position in the trunk of your vehicle. The panel with the Custom Covers label attached sits against the back of the rear seat, facing outward. Attach the Velcro sewn onto the underside of the liner directly to the carpet.

NOW FOR THE BACK OF THE SEATS ...

3. At the top of the seat area of the liner there are 6 lengths of material. Attach each of these around each pair of headrest poles and secure to the nearby Velcro sewn onto the liner.

NOW THE TAILGATE ...

4. Now attach 2 of the 18-inch-long Velcro strips supplied, to the Velcro strips sewn onto the tailgate of the liner and attach these directly to the tailgate trim using the liner as your guide.

NOW THE SIDES ...

5. Attach the 6 x 2-inch long Velcro strips, and the 2 x 27-inch long Velcro strips to the corresponding Velcro points along the top and rear end of each liner side. Using the liner as a guide, peeling off the backer on the adhesive-backed Velcro as you go, attach directly to the cargo area sides.

PART 2 - REMOVABLE BUMPER FLAP

6. Match the hook Velcro on the bumper flap to the loop Velcro sewn at the tailgate end of the liner.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD

IMPORTANT PREPARATION NOTES

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE VELCRO ADHESIVE TAKES 24HRS TO REACH FULL ADHESION.

