



## Fitting Instructions - Ford Ecosport Generation 2 Facelift version - 2018 onwards (470)

Fits the Fits version with small storage recesses on each side of the cargo area, and the floor height flush with the tailgate height.

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

This is a 2 part liner.

### PART 1 - THE MAIN LINER

#### ***ATTACH THE BASE FIRST ...***

1. Lay the liner in approximate position in the trunk of your vehicle. The panel with the Custom Covers label attached sits against the back of the rear seat, facing outward. Attach the Velcro sewn onto the underside of the liner directly to the carpet.

#### ***NOW FOR THE BACK OF THE SEATS ...***

2. At the top of the seat area of the liner there are lengths of material. Attach each of these around each headrest pole and secure back on to itself.

#### ***NOW THE SIDES ...***

3. Attach 2 x 2" long Velcro supplied (shown on Sketch A) to the corresponding Velcro points along each liner side plastic panels just behind the rears seats.
4. Using the liner as a guide, peeling off the backer on the adhesive-backed Velcro as you go, attach directly to the side trim. The remaining Velcro sew in the sides of the liner attach directly to the carpeted sides.

### PART 2 - REMOVABLE BUMPER FLAP

5. Match the hook Velcro on the bumper flap to the loop Velcro sewn at the tailgate end of the liner.

#### **PLEASE NOTE:**

**YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD**

**IMPORTANT PREPARATION NOTES**

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE

■ = Indicates areas where a 2" adhesive-backed Velcro piece needs to be applied

