



# NORTH AMERICAN CUSTOM COVERS

## Fitting Instructions - Land Rover Range Rover Evoque Quilted Liner 2011 Onwards (QBL219)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

### **IMPORTANT PREPARATION NOTES**

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. **ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE VELCRO ADHESIVE TAKES 24HRS TO REACH FULL ADHESION.**

This is a 2 part liner.

### **PART 1 - THE MAIN LINER**

#### ***ATTACH THE BASE FIRST ...***

1. Slide the storage net (located in the rear side panel) down so it sits flush with the floor.
2. Now lay the liner in approximate position in the boot of your vehicle. The panel with the UK Custom Covers label attached sits against the back of the rear seat, facing outward.
3. Starting at the tailgate end, neatly align and then press down the Velcro sewn onto the floor section of the liner directly to the carpet front and rear.

#### ***NOW FOR THE BACK OF THE SEATS ...***

4. Attached to the front of the liner are Velcro straps, align these to the headrest locator poles.
5. Pass the tapes around each headrest locator pole and Velcro back onto themselves.

#### ***NOW THE SIDES ...***

6. Carefully position the side panels neatly into place, the Velcro sewn onto the sides of the liner will attach directly to the carpet.

### **PART 2 - OPTIONAL TAILGATE PROTECTOR**

7. If you install this piece, before you start you'll need to cut the supplied Velcro as follows: 10 x 2" pieces.
8. Attach the pieces of Velcro that you've cut directly to the sewn in Velcro points on the tailgate protector, and using the liner as a guide fix to the tailgate.

**PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD. THE CARGO LINER WILL NOT ACCOMMODATE THE LOAD RETENTION SYSTEM.**

Velcro Fixing Kit - Tailgate Protector 10 x 2"  
(20" Supplied, Please cut to required lengths)