



Fitting Instructions - Jeep Grand Cherokee 2011 onwards (QBL302)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

IMPORTANT GENERIC PREPARATION NOTES

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE VELCRO ADHESIVE TAKES 24HRS TO REACH FULL ADHESION.

1. Before you start, if your Jeep has plastic sides you'll need to cut the supplied Velcro as follows for the main liner: 4 x 11" long pieces, 6 x 2" long pieces. Now lay the liner in approximate position in the trunk of your vehicle. The panel with the Custom Covers label attached sits against the back of the rear seat, facing outward.

ATTACH THE BASE FIRST ...

2. Starting at the tailgate end where the liner base meets the rear of the vehicle, attach the Velcro sewn onto the underside of the liner directly to the carpet.

NOW FOR THE BACK OF THE SEATS ...

3. At the top of the seat area of the liner there are 4 lengths of material and a central elastic strap for the middle headrest. Raise the headrests slightly and loop each around the headrest poles and secure back on to themselves.

NOW THE SIDES ...

4. If your Jeep has carpeted sides, the Velcro sewn in to the liner will attach directly to the carpet.

If your Jeep has plastic sides, attach the adhesive-backed Velcro pieces you cut earlier to the corresponding Velcro points on the liner sides. Carefully position the side panels neatly into place, working from the bottom upwards, and peeling off each backer piece as you go.

REMOVABLE BUMPER FLAP ...

5. Attach the separate bumper flap provided to the Velcro strip sewn along the tailgate end of the liner.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD