



Fitting Instructions - Porsche Cayenne Generation 2 - 2010 to 2018 (QBL631)

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

This is a 3 part liner.

Before installing, slide rear seats as far back as possible.

PART 1 - THE MAIN LINER

ATTACH THE BASE FIRST ...

1. Lay the liner in approximate position in the trunk of your vehicle. The panel with the Custom Covers label attached sits against the back of the rear seat, facing outward. Attach the Velcro sewn onto the underside of the liner directly to the carpet.

NOW FOR THE BACK OF THE SEATS ...

2. At the top of the seat area of the liner there are lengths of material. Attach each of these around each headrest pole and secure back on to itself.

NOW THE SIDES ...

3. Carefully position the side panels neatly into place, the Velcro sewn onto the sides of the liner will attach directly to the carpet.

PART 2 - REMOVABLE BUMPER FLAP

4. Match the hook Velcro on the bumper flap to the loop Velcro sewn at the tailgate end of the liner.

PART 2 - OPTIONAL UPPER TAILGATE PROTECTOR

5. If you install this piece, before you start you'll need to cut the supplied Velcro as follows: 19 x 2" pieces. Attach the pieces of Velcro that you've cut directly to the sewn in Velcro points on the tailgate protector and using the liner as a guide fix to the upper tailgate.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD. THE CARGO LINER WILL NOT ACCOMMODATE THE LOAD RETENTION SYSTEM.

IMPORTANT PREPARATION NOTES

Before attaching the self-adhesive Velcro to any car plastics/metal trim (NOT carpet); it is very important to remove any silicone film from the trim to ensure a good bond. Silicone is found in many valeting products and is also applied during manufacture. To remove any silicone build up the surface must be thoroughly cleaned using a silicone remover, we recommend 'Intensive tar remover' made by AutoGlym however a white spirit will also work just as well. Leave the area to dry for 10 minutes and wipe off any residue with a dry clean cloth after cleaning before applying the self-adhesive Velcro. ONCE THE VELCRO HAS COME INTO CONTACT WITH SILICONE RESIDUE IT CANNOT BE REUSED. THE

■ = Indicates areas where a 2" adhesive-backed Velcro piece needs to be applied

