



North American Custom Covers

Fitting Instructions - Mini Countryman Plugin Hybrid (QBL648) 2nd Generation (F60) 2017 onwards

Thank you for purchasing your cargo liner from our family-run business. Please follow the steps below to install your liner.

FITS VERSION WITH LEFT-HAND SIDE NETTING

SEATS MUST BE SET TO THE FULLY UPRIGHT POSITION

PART 1 - THE MAIN LINER

ATTACH THE BASE FIRST ...

1. Remove the load cover cassette and set rear seats to fully reclined. Lay the liner in approximate position in the trunk of your vehicle. The panel with the Custom Covers label attached sits against the back of the rear seat, facing outward.
2. Neatly align and then press down the Velcro sewn onto the floor section of the liner directly to the carpet on the base (see Sketch A).

NOW FOR THE BACK OF THE SEATS ...

3. At the top of the seat area of the liner there are 6 lengths of material. Attach each of the 6 around each headrest pole and secure back on to itself.

NOW THE SIDES ...

4. Carefully position the side panels neatly into place, the Velcro sewn onto the top sides of the liner will attach directly to the carpet.

PART 2 - REMOVABLE BUMPER FLAP

5. Match the hook Velcro on the bumper flap to the loop Velcro sewn at the tailgate end of the liner.

PLEASE NOTE: YOU MUST UNFASTEN THE VELCRO HEADREST STRAPS BEFORE PLACING THE REAR SEATS FORWARD

Sketch A
QBL648

